TOP AND CONSOLE PARTS

Electric Dryer

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)





FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8542740	Use & Care Guide
	LIT8541833	Tech Sheet
2		Top
	8519251	White
	3980096	Pewter
	8519252	Biscuit
3	8529983	Harness, Main
4		Panel, Console
	8530587	Platinum
	8530588	Blue
	3980188	Pewter
	3979788	Biscuit
5	3394427	Clip, Harness
6	8519271	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	3390647	Screw, 8−18 x 1/2
12	488886	Screw, 8−18 x 1/2
13	8519406	Bezel, Cycle
14	3936150	Connector, 7−Circuit
15	3395683	Connector, (Motor)
16	8281225	Screw, 8−18 x 1/2
17	2203186	Connector, 5−Circuit
18		Knob, Assembly
	46197020472	Platinum
	46197020471	Blue
	46197020742	Pewter
	46197020741	Biscuit
19		User Interface
	8530589	Platinum
	8530590	Blue
	3980189	Pewter
	3979789	Biscuit
20	8530591	Button, Start
21	8530592	Button, Pause/Cancel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1

(White/Platinum) (White/Blue) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8317342	Cover, Terminal Block
2	3390814	Screw, 8−18 x 3/8
3	697776	Screw, 10−32 x 5/8 (Ground)
4	3397659	Block, Terminal
5	3394881	Switch, Broken Belt
6	8521959	Dry Rack (Top)
7		Panel, Side (L.H.)
	8519209	White
	8519216	Pewter
	8519210	Biscuit
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12		Plug, Multivent
	697750	White
	3979261	Pewter
	3388311	Biscuit
13	3388672	Pulley Assembly
14	279318	Terminal, Brass & Tinned (3) (Includes Illus. 33)
15	8066120	Lever, Snap Switch
16	3394081	Wire, Belt Switch
17	8528076	Sound Panel
18	233520	Washer, Thrust
19	8283288	Wire, Jumper (Includes Illus. #41)
20	690997	Tri Ring
21	8066115	Cover−Plate
22	8529053	Ramp, Door
23	8521961	Dry Rack Support
24		Panel, Side (R.H.)
	8519213	White
	8519217	Pewter
	8519214	Biscuit
25	8521957	Dry Rack Assembly
26	3393657	Restrainer, Belt
27	8538263	Motor, Assembly 60 HZ.
28	3398948	Wire, Jumper (Broken Belt Switch)
29	3389729	Pulley 60 HZ.
30	3387610	Belt, Drive
32	3387118	Bracket, Motor
33	279393	Terminal Block Screw Kit (For Terminal Block)
34	49026	4" − 90° Elbow
36	3395532	Exhaust Pipe & Bracket
37	3395534	Exhaust Pipe (Short)
38	3395535	Exhaust Pipe (Long)
39	3388674	Idler Bracket
41	8519323	Switch, Door
42	98129	Screw, 6−20 x 1 1/16
43	3390647	Screw, 8−18 x 1/2
44	3387242	Seal, Front Panel
45	3393008	Screw, 10−16 x 1/2
46	8519459	Clip, Toe Panel
50	8519207	Base, Cabinet
51		Front Panel
	8519227	White
	3980074	Pewter
	3979765	Biscuit
52	696144	Strike, Door (2)
53	90767	Screw, 8−18 x 3/8
55	8299925	Harness, Digital Interface
56	8519273	Bracket, Control
57	3980062	Control Board
59	3400826	Screw, 8−18 x 3/4
61		Toe, Panel
	8519233	White
	3980095	Pewter
	8519234	Biscuit
62	8519219	Panel, Rear
63	692400	Nut, Push−In
64	343641	Screw, 10−16 x 1/2

Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

66	279818	White
	279969	Pewter
	279925	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1

(White/Platinum) (White/Blue) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread
2	3390647	Screw, 8−18 x 1/2
3	3394984	Door, Lint Screen
4	3406653	Harness, Sensor
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	3359452	Nut,3/8 x 16(R.H.)
9	8066086	Drum Hole Plug
10	3402841	Lens, Drum Light
11	8529005	Bracket, Lint Duct
12	3388229	Clip, Exhaust Pipe
13	3390646	Screw, 8−18 x 5/16
14	3387747	Heater Element
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
16	3387709	Nut, 3/8−16 (L.H.)
17	8520836	Bulkhead, Rear
18	3387459	Washer, Support
19	3399509	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	3402715	Exhaust Pipe
23	3394985	Housing, Outlet
24	8529007	Plug, Rear Bulkhead
25	8299966	Complete Drum Assembly
26	97787	Screw, 11−16 x 3/4
27	697694	Seal, Drum
28	695240	Screw, 8−18 x 1/2
29	90767	Screw, 8−18 x 3/8
30	8519221	Channel Bracket, Rear Bulkhead (2)
31	8519275	Bracket, Upper Rear Bulkhead
33	3406124	Bulb, Light
34	3387223	Electrode, Sensor
35	3977373	Bracket, Drum Light
36	3403634	Socket Assembly
37	697772	Wheel, Blower
39	3394986	Spring, Lint Screen Door
42	3976615	Thermistor
43	487909	Screw, 8−15 x 1/2
44	8541568	Housing, Blower
45	8530036	Lint Duct Assembly
46	3392537	Heater Box
47	8318314	Thermal Cut−Off (Includes Illus. 48)
48	3391914	Thermostat 295°F (146°C)
49	8066099	Bracket, Heater Box
51	3387230	Screw, 10−16 x 1
52	697771	Cover, Blower (Includes Illus. 62)
53	697693	Baffle, Drum
54	8519245	Bulkhead, Front
58	8299979	Grill, Outlet
59	3392519	Thermal Fuse
60	697770	Seal, Cover Plate
62	697769	Seal, Lint Duct
64	3390721	Lint, Screen

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4396174	Pewter
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4396175	Pewter
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
		ACCESSORY PARTS
	8529894	Kit, Hold Down
	8541503	Kit, Stack Assembly
	80047	Kit, Dryer Repair

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Plug, Hole (5)
	3404413	White
	3404417	Pewter
	3404415	Biscuit
2	8519419	Door Hinge Assembly
3	342043	Screw, 10−32 x 3/8
4	9742177	Screw, 8−18 x 5/8
5	8529539	Bracket, Handle
6	8529930	Pad, Door Handle
7		Handle, Door Assembly (LH)
	8529932	Platinum
	8529931	Blue
	3980077	Pewter
	3979775	Biscuit
		Handle, Door Assembly (RH)
	8529934	Platinum
	8529933	Blue
	3980210	Pewter
	3979776	Biscuit
8	3357011	Screw, 10−16 x 1/2
9		Door Assembly (Outer)
	8541574	Platinum
	8541573	Blue
	3980079	Pewter
	3977873	Biscuit

Illus. No.	Part No.	DESCRIPTION
10	8519309	Door Assembly (Inner)
11	355515	Screw, 8−18 x 11/16
14	8529540	Badge, Assembly
15		Filler Handle (LH)
	8528289	Platinum
	8528288	Blue
	3980082	Pewter
	3979771	Biscuit
		Filler Handle (RH)
	8528287	Platinum
	8528286	Blue
	3980101	Pewter
	3979772	Biscuit
16		Cover−Hinge, Stationary (LH)
	8528291	Platinum
	8528290	Blue
	3980100	Pewter
	3979777	Biscuit
		Cover−Hinge, Stationary (RH)
	8528293	Platinum
	8528292	Blue
	3980083	Pewter
	3979778	Biscuit

Illus. No.	Part No.	DESCRIPTION
17		Cover−Hinge, Rotating
	8528295	Platinum
	8528294	Blue
	3980084	Pewter
	3979779	Biscuit
18	25197190301	Clip, Trim Panel
19		Trim & Clip Assembly (Lower)
	8533767	Platinum
	8533766	Blue
	8533769	Pewter
	8533768	Biscuit
20		Trim & Clip Assembly (LH)
	8529526	Platinum
	8529525	Blue
	3980088	Pewter
	3979783	Biscuit
21		Trim & Clip Assembly (RH)
	8529528	Platinum
	8529527	Blue
	3980090	Pewter
	3979784	Biscuit
22		Kit, Door Reversing
	3979304	Platinum
	3979303	Blue
	3980097	Pewter
	3979770	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PEDESTAL PARTS (NOT INCLUDED)

For Models: GEW9200LW1, GEW9200LQ1, GEW9200LL1, GEW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8537141	Installation Instructions
	LIT8537342	Parts List
2		Drawer Front Assembly
	8537870	White
	8537871	Biscuit
	8537872	Graphite
	8537908	Pewter
3	8537883	Drawer Bin
4	8537875	Divider, Drawer (Set Of 2)
5	8537850	Slide Assembly
6	3400111	Screw
7	8537852	Foot Assembly
8	3400639	Screw, 6−20 x 3/8
9		Cabinet (Not Serviced)
10	3400842	Screw, 8−18 x 1/2
11	8537863	Pad (4)
12	8537853	Pan, Bottom
13	3400618	Screw

PED2700